

# UCAB232i

USB-RS232 Converter with Galvanic Isolation



### **Reference Manual**

ASIX s.r.o. Na Popelce 38/17 150 00 Prague Czech Republic

www.asix.net

support@asix.net

sales@asix.net

ASIX s.r.o. reserves the right to make changes to this document, the latest version of which can be found on the Internet.

ASIX s.r.o. renounces responsibility for any damage caused by the use of ASIX s.r.o. products.

© Copyright by ASIX s.r.o.

## **Table of Contents**

| 1 UCAE  | 3232i                                  | 4  |
|---------|--|----|
| 1.1 Pac | kage Contents                          | 4  |
| 1.2 Fea | atures                                 | 4  |
| 1.3 Usa | age                                    | 5  |
| 1.3.1   | RS232 interface                        | 5  |
|         | Data rate                              | 5  |
| 1.3.2   | LED indicators                         | 5  |
| 1.3.3   | Standby                                | 5  |
| 1.3.4   | Galvanic isolation                     | 6  |
| 1.3.5   | Durability to external influences      | 6  |
| 1.4 Tec | chnical Specification                  | 6  |
| 1.4.1   | Absolute Maximum Ratings               | 6  |
| 1.4.2   | Operating Specifications               | 6  |
| 1.4.3   | Certificates                           | 7  |
| 2 DRIV  | ERS                                    | 8  |
| 2.1 Dri | vers Installation                      | 8  |
| 2.1.1   | Windows                                | 8  |
|         | Windows 7 and newer                    | 8  |
|         | Older Windows versions                 | 8  |
| 2.1.2   | Linux                                  | 8  |
| Red     | ubleshooting and Special<br>quirements | 9  |
| 2.2.1   | Short time response needed             | 9  |
| 2.3 Use | er OEM Application                     | 9  |
| 3 Docu  | ment history                           | 11 |

## 1 UCAB232i

UCAB232i is a USB to RS232 converter with galvanic isolation. Using the UCAB232i converter it is possible to connect the most of RS232 devices to a USB port of a computer.

Thanks to the galvanic isolation the UCAB232i is suitable for industrial, automotive or commercial applications (e.g. mice, modems, data terminals, SmartCard readers, serial printers, measuring instruments with a serial port, industrial applications, etc.).

## 1.1 Package Contents

- UCAB232i Converter
- Leaflet

## 1.2 Features

Galvanic isolation:

5000 V DC / 1 sec. 2600 V AC / 1 min. 560 V RMS / no limit

• Enhanced ESD protection of all inputs

 $\pm 15$  kV air discharge HBM  $\pm 8$  kV contact discharge HBM

- Extended temperature range: -40 °C to +85 °C
- Enhanced durability against environmental influences
- Full RS232 implementation
- Based on FT232R
- Communication speed:

300 Baud - 250 kBaud, typ. to 500 kBaud

- Powered from USB
- Standard 9-pin SubD connector
- Receive buffer: 256 Byte
- Transmit buffer: 128 Byte
- Full hardware flow control using RTS/CTS, DTR/DSR, DCD, RI, hardware assisted XON/XOFF
- USB 1.1 and USB 2.0 compatible
- Possibility to customize VID, PID and its text ID for OEM products
- Drivers for Windows, Linux and Mac OS
- Low consumption mode support (USB suspend mode)
- Cable length: 1 m

### 1.3 Usage

After connection the UCAB232i to a computer and installing its drivers (see chapter Drivers) there will be added a new COM port to the operating system. The port can be accessed the standard way (e.g. using Win32 API functions).

It is possible to set the UCAB232i COM port number in the port properties in the Device manager.

#### 1.3.1 RS232 interface



Fig. 2: DB9, pins

UCAB232i provides all RS232 signals.

The description of RS232 signals is given in the following table:

| Pi<br>n | Name | I/O | Description         |
|---------|------|-----|---------------------|
| 1       | DCD  | IN  | Data Carrier Detect |
| 2       | RD   | IN  | Receive Data        |
| 3       | TD   | OUT | Transmit Data       |
| 4       | DTR  | OUT | Data Terminal Ready |
| 5       | SG   | PWR | Signal Ground       |
| 6       | DSR  | IN  | Data Set Ready      |
| 7       | RTS  | OUT | Request to Send     |
| 8       | CTS  | IN  | Clear to Send       |
| 9       | RI   | IN  | Ring Indicator      |

Table 1: RS232 signals description

#### Data rate

The data rate is within the range of 300 Baud to 250 kBaud, the converter is typically able to communicate faster but this cannot be guaranted. The usability for higher speeds can depend on temperature and signal quality of the connected device.

### 1.3.2 LED indicators

UCAB232i is equipped with two LED indicators.

Red LED: data are being sent from PC to a RS232 connected device  $% \left( {{\left[ {{{\rm{CD}}_{\rm{c}}} \right]}_{\rm{connected}}} \right)$ 

Green LED: data are being sent from a RS232 connected device to  $\ensuremath{\mathsf{PC}}$ 

#### 1.3.3 Standby

The UCAB232i converter supports PC standby mode (sleep).

#### 1.3.4 Galvanic isolation

The UCAB232i galvanically isolates both ports (USB, RS232) which protects the computer against the voltage of the device on the RS232 side with these limits:

- 5000 V DC maximally for 1 sec.
- 2600 V AC maximally for 1 min.
- 560 V RMS without any time limit



#### Warnings

UCAB232i does not comply with requirements in terms of safety separation.

Although, technically the UCAB232i converter assures the galvanic isolation within the limits listed above it does not comply with requirements in terms of safety separation according to EN 60730-1 standard.

ASIX s.r.o. is not liable for any damage caused due to any inappropriate use.

# 1.3.5 Durability to external influences

UCAB232i is designed and produced with regard to maximum durability to external influences. The operating temperature range is between -40 °C and +85 °C. In very low temperatures the cable becomes rigid, in such a case it has to be handled very carefully.

To improve characteristics a special passivation coat has been applied to the PCB of the converter.

The converter has been designed to comply with the IP50 specification.

## 1.4 Technical Specification

#### 1.4.1 Absolute Maximum Ratings

| Operating temperature                | min40 °C             | max. +85 °C |
|--------------------------------------|----------------------|-------------|
| Storage temperature                  | min55 °C             | max. +85 °C |
| Active USB current                   | max. 100 mA          |             |
| All input voltages to signal ground  | ±25 V                |             |
| All output voltages to signal ground | ±13 V                |             |
| USB to RS232 isolation               | 5 kV DC / 1 sec.     |             |
|                                      | 2.6 kV AC / 1 min.   |             |
|                                      | 560 V RMS / no limit | t           |
| ESD immunity                         | ±8 kV contact HBM    |             |
|                                      | ±15 kV air HBM       |             |
|                                      | ±15 kV Human Boo     | ly Model    |
| Electric Field Immunity              | 10V/m                |             |

Table 2: Absolute Maximum Ratings

#### 1.4.2 Operating Specifications

| Minimum data rate         | 300 Baud                                     |
|---------------------------|--|
| Maximum data rate         | 250 kBaud guaranteed,<br>500 kBaud typically |
| Supply current            | typ. 76 mA, in idle typ. 65 mA               |
| Supply current in sleep   | typ. 50 mA                                   |
| Input Treshold Low RS232  | min. 0.8 V, typ. 1.5 V                       |
| Input Treshold High RS232 | max. 2.4 V, typ. 1.8 V                       |

| Output voltage Swing <sup>1</sup> | min. ±5 V, typ. ±5.4 V          |
|-----------------------------------|---------------------------------|
| Short-circuit tolerance           | No limit                        |
| Short-circuit current             | maximum ±60 mA                  |
| Operating system                  | Windows <sup>2</sup> 32/ 64-bit |
|                                   | Linux 1.5.0 32/64-bit           |
|                                   | MAC OS 10 32/64-bit             |
|                                   | Windows CE <sup>3</sup>         |
| RS232                             | full implementation             |
| RS232 connector                   | DB9                             |
| USB 1.1 a 2.0 compatibility       | yes, 12 Mbps (Full Speed)       |
| USB connector                     | A type                          |
| Length of USB cable               | 1 m                             |
| Transmit indicator                | red LED                         |
| Receive indicator                 | green LED                       |
| IP Code                           | IP50                            |

Table 3: Operating Range

- <sup>1</sup> Outputs Loaded with 3 k $\Omega$ .
- <sup>2</sup> Windows 10, Windows 8, Windows 7, Windows Server, Windows Server 2003, Windows Vista, Windows XP. Compatible with 32/64 bit. version.
- <sup>3</sup> Windows Mobile 2003, Windows Mobile 2003 SE, Windows Mobile 5, Windows Mobile 6, Windows Mobile 6.1, Windows Mobile 6.5

#### 1.4.3 Certificates

| CE       | EN 55022 ed.3:2011          |
|----------|-----------------------------|
|          | EN 55024 ed.3:2011          |
| Immunity | EN61000-4-2, class B        |
|          | EN61000-4-3, class A 10 V/m |
|          | EN61000-4-8, class A        |
|          | EN55024, class A            |

Table 4: List of certificates



Fig. 3: CE certificate

## 2 DRIVERS

In this chapter we will discuss drivers installation and specific COM port setting requirements.

## 2.1 Drivers Installation

### 2.1.1 Windows

Drivers installation runs automatically from Windows Update. In case the computer is not on the Internet the drivers have to be manually installed same as for older Windows versions.

#### Note:

It is possible to set the converter COM port number in the Device manager.

#### Windows 7 and newer

With Windows 7 and newer the drivers are automatically installed from Windows Update after the UCAB232i cable has been connected to USB port. A message shown after the installation reports that the cable is ready to use.

Windows 10 does not show this message.

| Your device is ready to use                    |                           |  |
|--|---------------------------|--|
| USB Serial Converter<br>USB Serial Port (COM6) | Ready to use Ready to use |  |
|  |                           |  |

Fig. 4: Drivers installation

The drivers update automatically when the operating system updates.

#### **Older Windows versions**

In case of older Windows versions where the drivers do not install automatically they have to be downloaded from FTDI web (https://www.ftdichip.com).

Use VCP drivers (= Virtual COM Port).

The downloaded drivers have to be unpacked somewhere and when the system finds the cable as a new device the path to the unpacked drivers has to be provided to the installer. Or the drivers can be manually installed in the Device manager.

The installation is a two steps process, first it installs the converter driver then it installs the virtual COM port driver.

After the drivers are installed the cable is ready to use.

#### 2.1.2 Linux

Linux kernel 2.6.31 or newer includes required drivers and there is no need to install them.

There is a ftdi\_sio module. Most of GNU/Linux distributions is supplied with compiled ftdi\_sio module. The module version has to be 1.6.0 or newer. In most distributions the ftdi\_sio module is automatically loaded after the cable has been connected to a USB port.

## 2.2 Troubleshooting and Special Requirements

Some applications have special requirements for RS232 communication because of which the cable has to be particularly configured.

If there are difficulties in communication between the RS232 connected device and the PC there are several things to be checked.

Using the red LED it can be checked that the software application sends data on the correct PC port.

When the red LED is not blinking, no data are being transmitted by the software. This can happen when the application sends data to a different COM port number.

The COM port number can be checked and modified in the Ports section of the Device manager.

When the software sends some data but the connected device does not reply (green LED is not blinking), it is possible that there is not correctly set "Baud rate" (communication speed), "Data bits", "Parity", "Stop bits" or "Flow control". Please check that the settings meets specification of the connected device.

# 2.2.1 Short time response needed

If the connected device replies (green LED indicator blinks) but software application still does not receive data it is possible that the application needs shorter time response.

The USB communication works a different way than the RS232 communication. USB sends 64 B long packets. Furthermore, the device connected on the RS232 side can send its responce only on the PC request. Because of this it is very diffucult to achieve the response time under 1 ms.

Time response settings can be done in Device manager/ Ports/.../Port Settings/ /Latency Timer. In case of troubles set this number to 1 ms.

|     | Port Settings Driver Details   |                       |          |
|-----|--|-----------------------|----------|
|     | Bits per second: 9600  | •                     |          |
|     | Data bits: 8   | •                     |          |
|     | Parity: None   |                       |          |
|     | Stop bits: 1   | •                     |          |
|     | Flow control: None   | •                     |          |
|     |  |                       |          |
|     | Advanced Restore D   | efaults               |          |
| Adv | anced Settings for COM6  |                       | ?        |
|     |  |                       |          |
|     | COM Port Number: COM6  | •                     | ОК       |
|     | USB Transfer Sizes<br>Select lower settings to correct performance problems at | law baud rates        | Cancel   |
|     | Select higher settings for faster performance.                                 | iow badd rates.       | Defaults |
|     | Receive (Bytes): 4096  |                       |          |
|     | Transmit (Bytes):  |                       |          |
|     | BM Options   | Miscellaneous Options |          |
|     | Select lower settings to correct response problems.                            | Serial Enumerator     | [        |
|     |  | Serial Printer        | F        |
|     | Latency Timer (meec):  | orentari minter       |          |
|     | Latency Timer (msec):  | Cancel If Power Off   |          |

Fig. 5: COM port Enhanced Settings

## 2.3 User OEM Application

The UCAB232i converter enables user to make an OEM application, then the converter is reported as a customer hardware.

To do this the drivers have to be modified to change the converter VID and PID, which are originally set to 0403 / 6001, to customer numbers and using FT\_PROG utility to write these numbers to the converter EEPROM.

Before the EEPROM modification it is advisable to create a backup copy of its content in case there is any trouble with the new VID/PID identifiers.

For smooth installation of the modified driver on

Windows 7 and later the driver will have to be digitally signed. For more information on drivers signing see Microsoft web.

In Linux, the new VID and PID parameters have to be supplied to the ftdi\_sio module when it is loaded.

## **Document history**

| Document revision | Modifications made               |
|-------------------|----------------------------------|
| 2014-05-29        | Newly created document.          |
| 2014-06-11        | Drivers section updated.         |
| 2021-01-04        | Manual updated, address updated. |
|                   | Drivers chapter was updated.     |